

# Porting Your Code to the uVision Environment

by: **Chris Brown**

## Contents

1	Introduction.....	1
2	Overview of the KEIL Compiler.....	1
3	Common uVision Errors and Pitfalls.....	2
4	Creating a new Keil project from the Kinetis Sample Code .....	2
5	File Modifications.....	13
6	Checking your newly compiled project .....	26
7	Conclusion.....	26

## 1 Introduction

This application note is written for those who wish to use the Kinetis family sample code (KINETIS512\_SC, located at <http://www.freescale.com>) in the Keil uVision environment. It covers some general pitfalls that the Freescale Kinetis application team has discovered when trying to port to Keil and outlines one step-by-step example of porting a project from the Kinetis sample code to the Keil environment (targeted for the TWR-K60N512).

The current uVision release at the time of writing this application note is v4.23. The uVision IDE, offered by KEIL, is strictly ANSI C99 and CMSIS compliant. This can in turn cause compatibility issues with Freescale's sample code (or your code) as it is not CMSIS compliant.

## 2 Overview of the KEIL Compiler

KEIL uVision is an integrated development environment that combines project management, make facilities, source code editing, program debugging, and complete simulation in one powerful environment. KEIL uVision is a tool developed by ARM and has been supporting Freescale Kinetis products

since 2010. Because KEIL has close ties to ARM, KEIL is completely CMSIS compliant. More information about uVision can be found at <http://www.keil.com/uvision/>.

### 3 Common uVision Errors and Pitfalls

The following is a list of common errors that have been encountered by this group in the course of creating uVision projects.

- uVision strictly adheres to the C99 (ISO/IEC 9899) standard. Therefore, main must return a parameter of type int. In the current sample code base, main has a void return. uVision will not allow this and the definition of main must be changed to return an integer value.
- Keil does support inline assembly code. Setting up this function in uVision is difficult and not recommended. Many of the inline assembly functions throughout the sample code base must be changed to the CMSIS compliant intrinsic functions defined on Keil's website.
- If a variable or function is declared as an extern, it must be explicitly defined elsewhere in the code. If it is not, the uVision compiler will not be able to find the variable and errors will occur during the compilation.
- uVision by default does not allow anonymous union declarations, like those used in the current device specific header files. To enable the use of anonymous unions, you must use the instruction `#pragma anon_unions` to indicate to uVision that you will be using anonymous union declarations.
- The `__main` function of uVision initializes the stack and heap, as well as initializing variables. While you can call functions in the \*.s file before calling `__main`, you cannot have a function that jumps to another function (the stack is not setup). Also, you cannot depend on variables being set to a value in a function that was called before `__main`, because `__main` may clear this variable.

### 4 Creating a new Keil project from the Kinetis Sample Code

Currently, no Keil projects exist in the Kinetis sample code package. Therefore, you will need to create a folder, named Keil, under the KINETIS512\_SC\build folder. Next, you will need to create subfolders for your projects (the location for these folders will be KINETIS512\_SC\build\Keil\<project name>). After you have manually created your new project folder(s) in the location specified above, follow the step by step instructions to create your new uVision project.

1. Navigate to Project->New uVision Project....
2. Point the dialog box to the project folder you just created and save your new project there.
3. Select the appropriate Freescale MCU from the Generic CPU database (MK60N512VMD100 for this example). Do not be concerned that you can only select one part. There will be a chance to add other parts (or change the current part) later.

When prompted to copy the recommended `startup_<device>.s` file to the Project Folder and add the file to the project, click no. We will add our own \*.s file to the project later.


#### 4.1 Creating new targets and groups

Now you must add the project files to your project. But first, correctly setup the groups to organize your workspace. Follow these instructions to setup the workspace.


1. Click the Files, Extensions, Books, and Environments... dialog button.



2. A dialog box opens. Here you can add or modify targets and groups, as well as add or remove files to or from the groups. For convenience and organization, rename Target 1 to MK60N512 – Flash. Do this by double-clicking Target 1.




3. Rename Source Group 1 to Project, the same way that Target 1 was renamed. Before adding files to the groups, add all of the appropriate groups. The groups added are as follows:
  - common
  - drivers
  - cpu
  - platforms
4. Create a new project target (named MK60N512 – RAM) by clicking the “New (Insert)” button and name the newly created target appropriately. After the new target is created, it is necessary to perform the target setup actions described in [Memory configuration for a RAM target](#) for this target.
5. Click Ok to exit the Components, Environment and Books dialog box.




## 4.2 Memory configuration for a Flash target

1. Navigate to the Linker tab of the Target Options dialog box
2. Select Use Memory Layout from Target Dialog check box.




3. Select the Target tab. Ensure that the setup is the desired setup. For a Flash target, the flash memory addresses must be located in the IROM1 text boxes and the RAM memory locations must be entered in the IRAM1 and IRAM2 text boxes as displayed below.



#### NOTE

This memory configuration does not divide the RAM memory into two equal sections as described in the reference manual. If you need to maintain this structure or just need a third RAM section in general, consult the section on creating your own scatter loading file in this application note.


- Change the name of the executable produced when the project is compiled. This is executed mainly for convenience. Select the Output tab in the dialog box. In the Name of Executable text box, enter the name of the project followed by \_<Target>, where <Target> is the particular target type (that is, Flash or RAM). An example is shown in the following figure.




5. Click Ok to exit the Target Options dialog box.

### 4.3 Memory configuration for a RAM target

1. If you wish to run out of RAM, then you will need to modify these text boxes to the desired program RAM space entered in IROM1 and the other RAM memory locations are in IRAM1. For example, if you want to run this code from the lower half of RAM, the memory setup boxes need to be modified as follows.



- Change the name of the executable produced when the project is compiled. This is executed mainly for convenience. Select the Output tab in the dialog box. For the Name of Executable text box, enter the name of the project followed “\_<Target>”, where <Target> is the particular target type (that is, Flash or RAM). An example is shown below.



- Click Ok to exit the Target Options dialog box.

## 4.4 Adding files and include paths

Now that the groups are correctly setup, add the appropriate files to the groups.

Follow these instructions:

1. Right click on the group folder icon (listed in the group column of Table 1 below) in the Project pane and click the Add Files to Group '<folder name'...' button.
2. Then browse to the appropriate folder in the Add Files to Group dialog box, select the files in that folder, and click the Add button.

### NOTE

By default, uVision is set to find only source files, and finds header files automatically. Therefore, you will not need to add the header files, though you may want to add some header files manually if the file is modified often. The following table lists all of the files that are located in the sample project folder structure. Not all of these files will be used for every project and it is recommended that only necessary files be added to a project (the unnecessary files for the hello\_world example are in italics in the table).

**Table 1. Project file groupings**


Group	Files
Project	hello_world.c
common	<i>uif.c</i> alloc.c assert.c io.c <i>memtest.c</i> <i>printf.c</i> queue.c <i>startup.c</i> stdlib.c

*Table continues on the next page...*

**Table 1. Project file groupings  
(continued)**

Group	Files
drivers	<i>adc16.c</i> <i>nbuf.c</i> <i>enet.c</i> <i>eth_phy.c</i> <i>mii.c</i> <i>lptmr.c</i> <i>mcg.c</i> <i>pmc.c</i> <i>rtc.c</i> <i>uart.c</i> <i>wdog.c</i>
cpu	<i>arm_cm4.c</i> <i>start.c</i> <i>sysinit.c</i> <i>vectors.c</i>
platforms	<i>k60_tower.h</i> <i>k40_tower.h</i> <i>k53_tower.h</i>

3. In addition, you will need to copy *Retarget.c* and *Serial.c* to the UART driver folder (found at <Sample Code Root Directory>\src\drivers\uart) and add these files to your project. These files are necessary for the hardware UART to work correctly. *Retarget.c* is included with your uVision download and can be found at <Keil Installation Directory>\v4\_23\ARM\Startup. *Serial.c* is included with this application note.
4. After groups are created and the appropriate files have been added, setup the Include Paths, so that uVision is able to find all of the appropriate files, by typing the project relative paths into the Include Paths box (in a semicolon delimited list) in the C/C++ tab of the target options dialog box.



This setting will need to be added on a per target basis. The include paths that should be added are as follows:

```

..\<project_name>;
..\..\..\..\src\common;
..\..\..\..\src\cpu;
..\..\..\..\src\cpu\headers;
..\..\..\..\src\drivers\adc16;
..\..\..\..\src\drivers\mcp;
..\..\..\..\src\drivers\rtc;
..\..\..\..\src\platforms;
..\..\..\..\src\projects\<project_name>;
..\..\..\..\src\drivers\uart;
..\..\..\..\src\drivers\wdog;
..\..\..\..\src\drivers\pmb;
..\..\..\..\src\drivers\enet;
..\..\..\..\src\drivers\mcp;
..\..\..\..\src\drivers\rtc;
..\..\..\..\src\drivers\adc16;

```

```
..\..\src\drivers\lptmr
```

### Tip

Here are the paths as an in-line list for easy copying into the include paths text box:

```
..\Keil_ex1;..\..\src\common;..\..\src\cpu;..\..\src\cpu\headers;..\..\src\drivers\adc16;..\..\src\drivers\mcg;..\..\src\platforms;..\..\src\projects\hello_world;..\..\src\drivers\uart;..\..\src\drivers\wdog;..\..\src\drivers\pmc;..\..\src\drivers\lptmr
```


### NOTE

These file paths can be quickly added to your project by copying and pasting each of these into the target options or by copying and pasting the links from the example project included in this application note.

## 4.5 Creating a scatter file

Scatter files are used by the uVision environment to know where to place sections of code and variables. The scatter file is analogous to the linker file for other IDEs. These files can be generated automatically (as already shown here) or you can designate a custom scatter file for use by the IDE. If you have a scatter file you would like to use, go to the linker tab of the target options dialog box, uncheck “Use Memory Layout from Target Dialog and point uVision to the desired scatter file by clicking the “...” and browsing to the location of your scatter file.

Note that when you use your own custom scatter file, you must also ensure that the R/O Base address and the R/W Base address are correct.



For more information on creating your own scatter file, consult the uVision help files. An example of a three region scatter file written for an MK60X256 Flash target is shown below and provided with this application note.

```

01 ; *****
02 ; *** Scatter-Loading Description File generated by uVision ***
03 ; *****
04
05 LR_IROM1 0x00000000 0x00040000 { ; load region size_region
06 ER_IROM1 0x00000000 0x00040000 { ; load address = execution address
07 *.o (RESET, +First)
08 *(InRoot$$Sections)
09 .ANY (+RO)
10 }
11 RW_IRAM1 0x1FFF8440 0x00007BFO { ; RW data
12 .ANY (+RW +ZI)
13 mcg.o (+RO +ZI +RW)
14 }
15 RW_IRAM3 0x20000000 0x00008000 {
16 .ANY (+RW +ZI)
17 }
18 RW_IRAM2 0x1FFF8000 0x00000440 {
19 .ANY (+ZI +RW)
20 }
21 }
22
23 LR_IROM2 0x10000000 0x00040000 {
24 ER_IROM2 0x10000000 0x00040000 { ; load address = execution address
25 .ANY (+RO)
26 }
27 }

```

## 5 File Modifications

### 5.1 Device header file modifications

The current header file in this sample code base is not compatible with the uVision compiler. The uVision compiler does not by default allow the use of anonymous unions. Therefore, a #pragma statement is required to allow the compiler to use the anonymous unions located throughout the header files. Therefore, in the part header file (MKXXDZ10.h), some modifications are be required and these modifications are noted in the table below.

**Table 2. Device Header file modifications**

Line Number	Statements to add
248	#elif defined (__Keil) #pragma push #pragma anon_unions
15566	#elif defined (__Keil) #pragma pop

With these modifications, lines 241-253 should be written as shown below.

## File Modifications

```

00236
00237 /*
00238 ** Start of section using anonymous unions
00239 */
00240
00241 #if defined(__CWCC__)
00242     #pragma push
00243     #pragma cpp_extensions on
00244     #elif defined(__GNUC__)
00245         /* anonymous unions are enabled by default */
00246     #elif defined(__IAR_SYSTEMS_ICC__)
00247         #pragma language=extended
00248     #elif defined (__Keil)
00249         #pragma push
00250         #pragma anon_unions
00251     #else
00252         #error Not supported compiler type
00253     #endif
00254
00255 /* -----
00256     -- ADC
00257     ----- */

```

And lines 15560-15570 should be written as shown below.

```

15560
15561 /*
15562 ** End of section using anonymous unions
15563 */
15564
15565 #if defined(__CWCC__)
15566     #pragma pop
15567     #elif defined(__GNUC__)
15568         /* leave anonymous unions enabled */
15569     #elif defined(__IAR_SYSTEMS_ICC__)
15570         #pragma language=default
15571     #elif defined (__Keil)
15572         #pragma pop
15573     #else
15574         #error Not supported compiler type
15575     #endif
15576
15577 /**
15578  * @}
15579  */ /* end of group Peripheral_defines */
15580
15581
15582 /* -----
15583     -- Backward Compatibility
15584     -----

```

## 5.2 CPU folder file modifications

The CPU files include vectors.c, arm\_cm4.c, start.c, crt0.s, and sysinit.c. Begin with the modifications to start.c.

### 5.2.1 Start.c

The call to `__main` in uVision copies non-root (RO and RW) execution regions from their load addresses to their execution addresses, uncompresses necessary data sections, zeroes ZI regions, and then branches to `__rt_entry` (which sets up the stack and heap). Therefore, most of the `common_startup()` function is already in process and this function can be skipped using an `#ifndef` statement. However, `__main` does not copy the interrupt vectors, so you will need to add this function to `start()`. Therefore, lines 24-37 must now be as follows:

```

022 void start(void)
023 {
024     #ifndef __Keil
025     /* Disable the watchdog timer */
026     wdog_disable();
027
028     /* Copy any vector or data sections that need to be in RAM */
029     common_startup();
030     #endif
031
032     #ifdef __Keil
033
034     Relocate_ISR();
035
036     #endif
037
038     ...

```

The `Relocate_ISR()` function can be defined as a local function to `start.c`. The function is written as follows (and should be added to the end of `start.c`) and remember to add the function declaration to `start.h`.

```

303
304 void Relocate_ISR(void)
305 {
306
307     extern uint32 __vector_table[];
308
309     extern uint32 __VECTOR_RAM[];
310     uint16 n;
311
312     // Copy the vector table to RAM
313     if (__VECTOR_RAM != __vector_table)
314     {
315         for(n = 0; n < 0x104; n++)
316             __VECTOR_RAM[n] = __vector_table[n];
317     }
318
319     // Point the VTOR to the new copy of the vector table
320     SCB_VTOR = ((uint32)__VECTOR_RAM);
321
322 }
323

```

In addition, skip to the call to `main()`. Skipping the call to `main()` will require some project file modifications. To skip the call to `main()` in the `start` file, modify `start.c` as shown in the following:

```

066
067     #ifndef __Keil
068     /* Jump to main process */
069     main();
070
071
072     /* No actions to perform after this so wait forever */
073     while(1);
074
075     #endif
076 }
077 /*****

```

## 5.2.2 arm\_cm4.c

The files arm\_cm4.h and arm\_cm4.c also require modification. The main function of our sample code is defined in arm\_cm4.h. This has been defined as a function that returns nothing and accepts no arguments. However, uVision requires that main return an integer. Therefore, this definition will have to be changed in the declaration of main and lines 83-87 of arm\_cm4.h should now be as follows:

```

80 typedef volatile uint32      vuint32; /* 32 bits */
81
82 // function prototype for main function
83 #ifdef __Keil
84 int main(void);
85 #else
86 void main(void);
87 #endif

```

In addition, change the EnableInterrupts definition and DisableInterrupts definition (which are defined in arm\_cm4.h at lines 27 and 30) when using uVision. These macros must be changed because uVision does not implement inline assembly in the same manner as most IDEs in the market today. uVision uses a set of intrinsic functions defined in the CMSIS standard for implementing the inline assembly instructions that are typically used throughout the sample code. Modifying the macro defined in arm\_cm4.h saves valuable time and frustration when compiling the sample code in uVision. Therefore, the new macro definitions must look as follows:

```

024
025 /*****
026  < Macro to enable all interrupts. */
027 #ifdef __Keil
028 #define EnableInterrupts __enable_irq();
029 #else
030 #define EnableInterrupts asm(" CPSIE 1");
031 #endif
032
033 /*****
034  < Macro to disable all interrupts. */
035 #ifdef __Keil
036 #define DisableInterrupts __disable_irq();
037 #else
038 #define DisableInterrupts asm(" CPSID 1");
039 #endif
040 /*****

```

## 5.2.3 arm\_cm4.c

The file arm\_cm4.c currently defines the stop() and wait() functions. These functions use inline assembly instructions which as previously described, are not allowed in the uVision environment. Therefore, you need to modify those function calls to use the CMSIS defined intrinsic functions. The modified stop() function will now appear as follows:

```

021
022 void stop (void)
023 (
024     /* Set the SLEEPDEEP bit to enable deep sleep mode (STOP) */
025     SCB_SCR |= SCB_SCR_SLEEPDEEP_MASK;
026
027     /* WFI instruction will start entry into STOP mode */
028     #ifdef __Keil
029     __wfi();
030     #else
031     asm("WFI");
032     #endif
033 )

```

And the wait() function will now appear as follows:

```

040
041
042
043
044
045
046 void wait (void)
047 (
048     /* Clear the SLEEPDEEP bit to make sure we go into WAIT
049     * of deep sleep.
050     */
051     SCB_SCR &= ~SCB_SCR_SLEEPDEEP_MASK;
052
053     /* WFI instruction will start entry into WAIT mode */
054     #ifdef __Keil
055     __wfi();
056     #else
057     asm("WFI");
058     #endif
059 )
060 /******

```

## 5.2.4 crt0.s

Copy the current crt0.s file, rename it crt0\_keil.s and add the newly created crt0.s file to the project. This file will need to be modified for the uVision environment. Firstly, uVision uses the semicolon (;) to denote that an entire line is a comment. This will be the first change you will want to make.

The current crt0.s file simply initializes the general purpose core registers to '0' and then calls the start function. In the uVision environment, the symbols Stack\_Mem and Heap\_Mem must be defined. The compiler looks for these symbols, by default in the startup assembly file. Therefore, you will need to define these symbols in your crt0.s file.

In addition, you will want to define \_\_initial\_sp and assign it to a known value. This variable tells the uVision environment where to start the stack. By default, the stack will grow down, so this variable should be assigned to the end of the RAM memory space minus eight. To do this, insert the following code at the beginning of the crt0.s file.

## File Modifications

```

015 ; <h> Stack Configuration
016 ; <o> Stack Size (in Bytes) <0x0-0xFFFFFFFF:8>
017 ; </h>
018
019 Stack_Size      EQU      0x00000400
020
021                AREA     STACK, NOINIT, READWRITE, ALIGN=3
022 Stack_Mem       SPACE    Stack_Size
023 __initial_sp    EQU      0x2000FFFB
024
025
026 ; <h> Heap Configuration
027 ; <o> Heap Size (in Bytes) <0x0-0xFFFFFFFF:8>
028 ; </h>
029
030 Heap_Size       EQU      0x00000200
031
032                AREA     HEAP, NOINIT, READWRITE, ALIGN=3
033 __heap_base     EQU      __initial_sp
034 Heap_Mem        SPACE    Heap_Size
035 __heap_limit    EQU      __initial_sp+Heap_Size
036
037
038                PRESERVE8
039                THUMB

```

Before defining the reset procedure, setup the reset area and let the compiler know about the interrupt vector table by importing the vector table from vectors.c (Note — vectors.c does require modifications for this to work). Insert the following code into the crt0.s file.

```

041
042 ; Vector Table Mapped to Address 0 at Reset
043
044                AREA     RESET, DATA, READONLY
045                IMPORT   __vector_table
046
047
048                AREA     |.text|, CODE, READONLY
049
050
051 ; Define the location of the interrupt vectors in RAM space
052 __VECTOR_RAM    EQU      0x1fff0000
053

```

Now the Reset handler must be defined. uVision will setup the code such that the program begins at the Reset handler upon a reset. The current code in crt0.s can be used to insert the following into your crt0\_keil.s file.

```

054 ; Reset Handler
055
056 Reset_Handler PROC
057     IMPORT wdog_disable
058     IMPORT __main
059     EXPORT __initial_sp
060     EXPORT __VECTOR_RAM
061     EXPORT Reset_Handler [WEAK]
062     EXPORT __startup
063 __startup
064     MOV     r0,#0           ; Initialize the GPRs
065     MOV     r1,#0
066     MOV     r2,#0
067     MOV     r3,#0
068     MOV     r4,#0
069     MOV     r5,#0
070     MOV     r6,#0
071     MOV     r7,#0
072     MOV     r8,#0
073     MOV     r9,#0
074     MOV     r10,#0
075     MOV     r11,#0
076     MOV     r12,#0
077     CPSIE  i             ; Unmask interrupts
078     LDR     RO, =wdog_disable
079     BLX     RO
080     LDR     RO, =__main
081     BX      RO
082     ENDP
083
084
085     ALIGN
086 noc
    
```

Notice that the code from the original crt0.s is in the reset handler routine. The reset handler makes itself, the boot stack address, and the startup sequence (initialization of the general purpose registers) available to other parts of the program. Then it calls the watchdog disable function located in wdog.c. Then it will branch back to this file, where `__main` will be called. `__main` is the entry point of a uVision program performs the important following functions:

1. Copies non-root (RO and RW) execution regions from their load addresses to their execution addresses. Also, if any data sections are compressed, they are decompressed from the load address to the execution address.
2. Zeroes ZI regions
3. Branches to `__rt_entry`

`__rt_entry` performs the following actions:

1. Sets up the stack and the heap by one of a number of means that include calling `__user_setup_stackheap()`, calling `__rt_stackheap_init()`, or loading the absolute addresses of scatter-loaded regions.
2. Calls `__rt_lib_init()` to initialize referenced library functions, initialize the locale and, if necessary, setup `arc` and `argv` for `main()` (user defined main). For C++, calls the constructors for any top-level objects by way of `__cpp_initialize_aeabi_`.
3. Calls `main()`, the user-level root of the application.
4. Calls `exit()` with the value returned by `main()`.

Finally, the assembly file ends with special instructions if you are using the Microlib library. The section of code to perform this setup must be located at the end of this file.

```

000
006 ; User Initial Stack & Heap
007
008     IF      :DEF: __MICROLIB
009
010         EXPORT  __initial_sp
011         EXPORT  __heap_base
012         EXPORT  __heap_limit
013
014     ELSE
015
016         IMPORT  __use_two_region_memory
017         EXPORT  __user_initial_stackheap
018 __user_initial_stackheap
019
020         LDR    R0, = Heap_Mem
021         LDR    R1, =(Stack_Mem + Stack_Size)
022         LDR    R2, =(Heap_Mem + Heap_Size)
023         LDR    R3, = Stack_Mem
024         BX    LR
025
026     ALIGN
027
028     ENDIF
029
030     END
031
032
033
034
035
036
037
038
039
040
041
042
043
044
045
046
047
048
049
050
051
052
053
054
055
056
057
058
059
060
061
062
063
064
065
066
067
068
069
070
071
072
073
074
075
076
077
078
079
080
081
082
083
084
085
086
087
088
089
090
091
092
093
094
095
096
097
098
099
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114

```

## 5.2.5 vectors.c

Now that the assembly startup file is written (and references vectors.c), modify vectors.c for operation in the uVision environment. Modify the #if statement to include a uVision option defining the vector table array and indicate to the linker where to put this array. To do this, insert the following code into the #if statement of vectors.c found at line 16.

```

011 /******
012 * Vector Table
013 *****/
014 typedef void (*vector_entry)(void);
015
016 #if defined(IAR)
017     #pragma location = ".intvec"
018     const vector_entry __vector_table[] = /*@ ".intvec" =
019 #elif defined(CW)
020     #pragma define_section vectortable ".vectortable" ".vectortable" ".vectortable" far_abs R
021     #define VECTOR __declspec(vectortable)
022     const VECTOR vector_entry __vector_table[] = /*@ ".intvec" =
023 #elif defined(Keil)
024     const vector_entry __attribute__((section(".ARM.__at_0x00"))) __vector_table[] = /*@ ".int:
025 #endif
026
027 (
028     VECTOR_000,      /* Initial SP      */
029     VECTOR_001,      /* Initial PC      */
030     VECTOR_002,

```

For more information on the \_\_attribute\_ command, refer to the uVision help files.

## 5.2.6 vectors.h

The first two vectors in the vector table need to point to the initial stack pointer and the Reset\_Handler. Therefore, you will need to modify vectors.h as follows:

```

022
023 extern void __startup(void);
024 extern void Reset_Handler(void);
025
026 extern unsigned long __BOOT_STACK_ADDRESS[];
027 extern unsigned long __initial_sp[];
028 extern void __iar_program_start(void);
029
030 #ifdef __Keil
031 #define VECTOR_000      (pointer*)__initial_sp
032 #define VECTOR_001      Reset_Handler
033 #else
034
035 // Address      Vector IRQ
036 #define VECTOR_000      (pointer*)__BOOT_STACK_ADDRESS //
037 #define VECTOR_001      __startup // 0x0000_0004 1 -      ARM
038 #endif
039 #define VECTOR_002      default_isr // 0x0000_0008 2 -
040 #define VECTOR_003      default_isr // 0x0000_000C 3 -

```

## 5.3 Common folder file modifications

The common files include uif.c, uif.h, alloc.c, assert.c, io.c, io.h, memtest.c, memtest.h, printf.c, queue.c, queue.h, startup.c, stdlib.c, and stdlib.h. We will begin with the modifications to alloc.c.

### 5.3.1 common.h

The header file common.h contains a selection statement that selects a compiler specific header file based on the compiler being used. To eliminate the warning when using the uVision IDE, a modification to this code is necessary. At line 61, insert the following code.

```

54 /*
55  * Include any toolchain specific header files
56  */
57 #if (defined(CW))
58   #include "cw.h"
59 #elif (defined(IAR))
60   #include "iar.h"
61 #elif (defined(__Keil))
62 #else
63 #warning "No toolchain specific header included"
64 #endif
65 ..

```

### 5.3.2 alloc.c

In alloc.c, there are compiler specific #if statements that define variables necessary for the malloc function. The variables \_\_HEAP\_START and \_\_HEAP\_END are populated from linker symbols. To populate these in uVision, use of the uVision specific linker symbols are needed. Therefore, insert the following code at line 85 such that lines 80-91 are as follows:

```

079     /* Get addresses for the HEAP start and end */
080     #if (defined(CW))
081         extern char __HEAP_START;
082         extern char __HEAP_END[];
083     #elif (defined(IAR))
084         char* __HEAP_START = __section_begin("HEAP");
085         char* __HEAP_END = __section_end("HEAP");
086     #elif (defined(__Keil))
087         extern uint32_t HEAP$$Base;
088         extern uint32_t HEAP$$Limit;
089         uint32_t __HEAP_START = (uint32_t) &HEAP$$Base;
090         uint32_t __HEAP_END = (uint32_t) &HEAP$$Limit;
091     #endif
092

```

## 5.4 Driver file modifications

The only driver files that need modification are the mcg.h and mcg.c files. These files have IDE specific declarations for the set\_sys\_dividers subroutine because this subroutine needs to be placed in RAM memory due to an errata (Errata e2448) on the Kinetis family 0M33Z mask set. Placing this function in RAM memory allows the code base to be compatible with all Kinetis family revisions. (Specifying the code location of functions are discussed in the next section.) For now, the focus is on the changes to the code in the driver files.

### 5.4.1 mcg.h

To make these files uVision compatible, add an #if statement to define the function when using uVision. In the header file, mcg.h, lines 40-47 must be written as follows:

```

39
40 #if (defined(IAR))
41     __ramfunc void set_sys_dividers(uint32 outdiv1, uint32 outdiv2, uint32 outdiv3, uint32 outdiv4);
42 #elif (defined(CW))
43     __relocate_code__
44     void set_sys_dividers(uint32 outdiv1, uint32 outdiv2, uint32 outdiv3, uint32 outdiv4);
45 #elif (defined(__Keil))
46     void set_sys_dividers(uint32 outdiv1, uint32 outdiv2, uint32 outdiv3, uint32 outdiv4);
47 #endif
48
39
40 #if (defined(IAR))
41     __ramfunc void set_sys_dividers(uint32 outdiv1, uint32 outdiv2, uint32 outdiv3, uint32 outdiv4);
42 #elif (defined(CW))
43     __relocate_code__
44     void set_sys_dividers(uint32 outdiv1, uint32 outdiv2, uint32 outdiv3, uint32 outdiv4);
45 #elif (defined(__Keil))
46     void set_sys_dividers(uint32 outdiv1, uint32 outdiv2, uint32 outdiv3, uint32 outdiv4);
47 #endif
48

```

### 5.4.2 mcg.c

In the source file, mcg.c, lines 141-148 must be written as follows:

```

140  */
141  #if (defined(IAR))
142  __ramfunc void set_sys_dividers(uint32 outdiv1, uint32 outdiv2, uint32 outdiv3, uint32 outdiv4)
143  #elif (defined(CW))
144  __relocate_code
145  void set_sys_dividers(uint32 outdiv1, uint32 outdiv2, uint32 outdiv3, uint32 outdiv4)
146  #elif (defined(__Keil))
147  void set_sys_dividers(uint32 outdiv1, uint32 outdiv2, uint32 outdiv3, uint32 outdiv4)
148  #endif
149  (

```

In addition to these changes, the source file declares variables `drs_val` and `dmx32_val` as externs, and they have not been explicitly defined elsewhere in the program. As mentioned previously, the uVision environment does not allow this coding practice. Therefore, at line 23, the word `extern` must be removed from the statement and the code should now be written as follows:

```

020 extern int core_clk_khz;
021 extern int core_clk_mhz;
022 extern int periph_clk_khz;
023 char drs_val, dmx32_val;
024

```

### 5.4.3 enet.c

The Ethernet driver files use an inline assembly instruction call to implement a wait function. However, as previously mentioned, the uVision environment does not accommodate these instructions. Therefore, you will need to modify the `enet_reset` function at line 134 in `enet.c` to the following:


```

132  */
133  void
134  enet_reset (int ch)
135  (
136      int i;
137
138      /* Set the Reset bit and clear the Enable bit */
139      ENET_ECR/**(ch)*/ = ENET_ECR_RESET_MASK;
140
141      /* Wait at least 8 clock cycles */
142      for (i=0; i<10; ++i)
143      (
144          #ifdef __Keil
145              __NOP;
146          #else
147              asm( "NOP" );
148          #endif
149      )
150  )

```

## 5.5 Specifying memory locations for code and variables

It is beneficial to be able to specify where specific functions and variables reside in memory. For example, one errata against the Kinetis part requires that certain functions within the MCG driver be placed in RAM memory. uVision does not allow specific functions to be placed in specific locations in memory. However, it does allow you to place entire files or variables into specific places in memory. If you are allowing uVision to create your scatter file, then you can place an entire file in RAM memory by right clicking on the file (try this with `mcg.c`) and selecting Options. In the Options dialog box for the file, select the desired location for the Code/Const parameter in the Memory Assignment section (shown below). In this particular case, you want to select IRAM2, this is the location of our internal RAM memory.



If you have created your own scatter file, you can specify where in memory to place that file by listing the associated \*.o file in the desired section of code. Consider mcg.c again. To place this file in RAM memory when using a predefined scatter file, just list mcg.o in the desired RAM location. The following figure shows an example of this.

## 5.6 Using the Hardware UART

The uVision environment provides semi-hosting support and is configured for this by default. For the printf() function to send data to the hardware UART (and not the debugger console), the Keil provided retarget.c, Serial.h, and Serial.c must be used. These files disable semi-hosting and retarget the library functions that use semi-hosting.

### 5.6.1 Retarget.c

Retarget.c is found in <root>\Keil\vXXX\ARM\Startup\Retarget.c, where vXXX is your uVision version number. Keep in mind that it must be copied into your local folder structure when adding it to the project. This file is where semi-hosting is disabled and where most of the retargeting is performed. Minor modifications are required for proper operation. The functions fputc() and \_ttywrch() should return SER\_PutChar() instead of their default return values. These functions are found in Serial.c, so you must include Serial.h at the top of Retarget.c. The necessary modifications should result in the following code:

```

28
29 int fputc(int ch, FILE *f) {
30     //return (sendchar(ch));
31     return (SER_PutChar(ch));
32 }
33

```

```

45
46 void _ttywrch(int ch) {
47     //sendchar (ch);
48     SER_PutChar(ch);
49 }
50
51

```

The function, `fgetc()`, should return `SER_GetChar()` instead of its default return value. This function is found in `Serial.c` and the appropriate header should be included at the top of `Retarget.c`. The necessary modifications to this function should result in the following:

```

37
38 int fgetc(FILE *f) {
39     //return (getkey());
40     return (SER_GetChar());
41 }
42

```

## 5.6.2 Serial.c

`Serial.c` is provided with this application note and implements the `SER_PutChar` subroutine and `SER_GetChar` subroutines while still providing support for semi-hosting if desired. It is important to note that it implements a polled UART and the particular UART used is the UART defined by `TERM_PORT`. The `SER_PutChar` and `SER_GetChar` subroutines are displayed below.

```

31 /*-----
32 *       SER_PutChar: Write a character to the Serial Port
33 *-----*/
34 int32_t SER_PutChar (int32_t ch) {
35     #ifdef __DBG_ITM
36         int i;
37         ITM_SendChar (ch & 0xFF);
38         for (i = 10000; i; i--);
39     #else
40         // Wait until space is available in the FIFO //
41         while (!(UART_S1_REG(TERM_PORT) & UART_S1_TDRE_MASK))
42             ();
43         // Now Send the character //
44         UART_D_REG(TERM_PORT) = (uint8_t)ch;
45     #endif
46     return (ch & 0xFF);
47 }
48
49
50

```

## Checking your newly compiled project

```

51
52 /*-----
53  *   SER_GetChar: Read a character from the Serial Port
54  *-----*/
55 int32_t SER_GetChar (void) {
56 #ifdef __DBG_ITM
57     if (ITM_CheckChar())
58         return ITM_ReceiveChar();
59 #else
60     // Wait until character has been received //
61     while (!(UART_S1_REG(TERM_PORT) & UART_S1_RDRF_MASK));
62
63     // Return the 8-bit data from the receiver //
64     return UART_D_REG(TERM_PORT);
65
66 #endif
67 }
68
69

```

## 5.7 Project file modifications

Since the majority of the changes have been taken care of in the common files, there should be minimal changes to your project files. In the interest of being brief, the necessary source file modifications for all of the sample code projects are not covered here. With this in mind, the following bullet points should aid in porting your sample code to the uVision environment.

- Since the declaration of main has been changed to be ANSI C99 compliant, you will also need to change the definition of main to be C99 compliant in the source.
- The first action the main must take is to call start(). With the modifications made, the startup assembly file does not call the start function, and therefore, the clocks and the UART will not be properly initialized unless this function is called.
- Some interrupt vectors may still be defined in a way that will not be accepted by the uVision environment. If your compilation attempt returns errors due to an interrupt vector assignment, change the interrupt vector assignment so that it first undefines the desired interrupt vector number, and then redefines this vector number as the name of the interrupt routine you have written.
- The uVision console library does not automatically add a '\r' character when using the '\n' character in print statements. You may want pr need to add these characters to your print statements for formatting purposes.

## 6 Checking your newly compiled project

When developing a new application, it is often beneficial to check that the generated code is within your size and location constraints. The uVision environment does not automatically update an output folder with the linker map, as is done in many other IDEs. However, you can still view these files by navigating to the build folder and dragging the desired file into the uVision environment.

## 7 Conclusion

This application note provides the basic concepts for porting your code to the uVision environment. It has shown how to leverage uVision's built in features to be able to easily configure a project for a different target.

The examples provided are specifically aimed at the Kinetis MK60N512 part but the concepts could be easily implemented on other parts as well.

## **How to Reach Us:**

### **Home Page:**

[www.freescale.com](http://www.freescale.com)

### **Web Support:**

<http://www.freescale.com/support>

### **USA/Europe or Locations Not Listed:**

Freescale Semiconductor  
Technical Information Center, EL516  
2100 East Elliot Road  
Tempe, Arizona 85284  
+1-800-521-6274 or +1-480-768-2130  
[www.freescale.com/support](http://www.freescale.com/support)

### **Europe, Middle East, and Africa:**

Freescale Halbleiter Deutschland GmbH  
Technical Information Center  
Schatzbogen 7  
81829 Muenchen, Germany  
+44 1296 380 456 (English)  
+46 8 52200080 (English)  
+49 89 92103 559 (German)  
+33 1 69 35 48 48 (French)  
[www.freescale.com/support](http://www.freescale.com/support)

### **Japan:**

Freescale Semiconductor Japan Ltd.  
Headquarters  
ARCO Tower 15F  
1-8-1, Shimo-Meguro, Meguro-ku,  
Tokyo 153-0064  
Japan  
0120 191014 or +81 3 5437 9125  
[support.japan@freescale.com](mailto:support.japan@freescale.com)

### **Asia/Pacific:**

Freescale Semiconductor China Ltd.  
Exchange Building 23F  
No. 118 Jianguo Road  
Chaoyang District  
Beijing 100022  
China  
+86 10 5879 8000  
[support.asia@freescale.com](mailto:support.asia@freescale.com)

Information in this document is provided solely to enable system and software implementers to use Freescale Semiconductors products. There are no express or implied copyright licenses granted hereunder to design or fabricate any integrated circuits or integrated circuits based on the information in this document.

Freescale Semiconductor reserves the right to make changes without further notice to any products herein. Freescale Semiconductor makes no warranty, representation, or guarantee regarding the suitability of its products for any particular purpose, nor does Freescale Semiconductor assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any liability, including without limitation consequential or incidental damages. "Typical" parameters that may be provided in Freescale Semiconductor data sheets and/or specifications can and do vary in different applications and actual performance may vary over time. All operating parameters, including "Typicals", must be validated for each customer application by customer's technical experts. Freescale Semiconductor does not convey any license under its patent rights nor the rights of others. Freescale Semiconductor products are not designed, intended, or authorized for use as components in systems intended for surgical implant into the body, or other applications intended to support or sustain life, or for any other application in which failure of the Freescale Semiconductor product could create a situation where personal injury or death may occur. Should Buyer purchase or use Freescale Semiconductor products for any such unintended or unauthorized application, Buyer shall indemnify Freescale Semiconductor and its officers, employees, subsidiaries, affiliates, and distributors harmless against all claims, costs, damages, and expenses, and reasonable attorney fees arising out of, directly or indirectly, any claim of personal injury or death associated with such unintended or unauthorized use, even if such claims alleges that Freescale Semiconductor was negligent regarding the design or manufacture of the part.

RoHS-compliant and/or Pb-free versions of Freescale products have the functionality and electrical characteristics as their non-RoHS-complaint and/or non-Pb-free counterparts. For further information, see <http://www.freescale.com> or contact your Freescale sales representative.

For information on Freescale's Environmental Products program, go to <http://www.freescale.com/epp>.

Freescale™ and the Freescale logo are trademarks of Freescale Semiconductor, Inc. All other product or service names are the property of their respective owners.

© 2012 Freescale Semiconductor, Inc.