

TWR-SER Jumper Configuration

Jumper	Position
J10	1 - 2
J16	3 -4
J2	1 - 2

TWR-S08MM128 Jumper Configuration

Jumper	Position
J1	Connected
J3	Open
J4	Open
J5	Open
J6	Connected
J7	Open
J8	Open
J9	Connected
J10	2-3
J11	Connected
J12	Open
J15	1-2
J16	1-2
J18 1-2	Open
J18 3-4	Connected
J18 5-6	Connected
J18 7-8	Connected
J18 9-10	Open
J18 11-12	Open
J18 13-14	Open
J20	Open
J24	Open
J25 1-2	Open
J25 3-4	Connected
J25 5-6	Connected
J26	2-3

TWR-MCF51MM Jumper Configuration

Jumper	Position
J1	Connected
J3	Open
J4	Open
J5	Open
J6	Connected
J7	Open
J8	Open
J9	Connected
J10	2-3
J11	Connected
J12	Open
J15	1-2
J16	1-2
J18 1-2	Open
J18 3-4	Connected
J18 5-6	Connected
J18 7-8	Connected
J18 9-10	Open
J18 11-12	Open
J18 13-14	Open
J20	Open
J24	Open
J25 1-2	Open
J25 3-4	Connected
J25 5-6	Connected
J26	2-3

TWR-K53N512 Jumper Configuration

Jumper	Position
J1	Open
J3	Open
J4	2-3
J5	Open
J6	Connected

J7	Connected
J11	1-2
J12	Open
J14	Open
J15	Connected
J16	1-2
J17	Connected
J18	Connected
J20	Open
J21	Connected
J22	Open
J24	1-2
J25	Open
J26	Open
J28	Open
J29	Connected
J32	1-2
J33	1-2
J34	Open

MED-EKG Jumper Configuration

Jumper	Position
J2	1-2
J3	1-2
J4	1-2
J5	Open
J6	2-3
J7	2-3
J8	2-3
J9	2-3
J11	2-3