

# Demo Set-up

---

The SW MC56F84000\_PWM\_ADC\_3trigger\_single\_channel demonstrates ADC and ePWM functionality, where in a single PWM cycle ADC is taking reading 3 times which can be used in slope compensation. It also has FreeMASTER communication with a PC Computer. It is targeted at MC56F84789 and its derivatives.

## H/W Setup

The h/w consists of:

1. MAPS-MC56F84000 populated with MC56F84789 device
2. USB cable connected to MAPS OSBDM connector
3. 5V Power supply

Before the demo starts, the HW with OSBDM link needs to be set-up.

## Application SW

The demo s/w is located in a folder MC56F84000\_PWM\_ADC\_3trigger\_single\_channel. The s/w was designed using CodeWarrior CW10.x

## Development Tools

In order to compile run, load and flash the demo the following s/w is necessary to:

1. Install CodeWarrior\_CW\_MCU\_v10.x and Run the CodeWarrior
2. Drag and drop < MC56F84000\_PWM\_ADC\_3trigger\_single\_channel\project into the opened CodeWarrior CW10.x
3. Clean(if the project is the first time run in your workspace) and Build the application code target MC56F84789\_Internal\_PFlash\_SDM
4. Connect a USB cable between the PC host and the mbed USB port (CN7 on the MAPS-56F84000 board).
5. Running/debugging loading the code:
  - a. Run -> Debug Configuration
  - b. Set the configuration for debug as download for SDM module.
6. Click Debug
7. Start


## Running the demo

Demo is to be controlled using a FreeMASTER communication tool. In order to control the application the following sw is necessary:


1. FreeMASTER Application Installation  
[http://www.freescale.com/webapp/sps/site/prod\\_summary.jsp?code=FREEMASTER&parentCode=null](http://www.freescale.com/webapp/sps/site/prod_summary.jsp?code=FREEMASTER&parentCode=null)
2. CodeWarrior Connection Server  
this is a part of Freescale CodeWarrior installation, located usually at C:\Freescale\CW MCU v10.6\MCU\ccs\bin  
but the ccs\_bld000\_win.zip can also be obtained without the CodeWarrior installation

The following steps are necessary (if continuing from debug mode, go to step 4 and when freemaster is in run state, terminate the code from CodeWarrior using terminate button):

1. Connect Power Supply
2. Connect OSBDM for FreeMASTER control
3. If the application s/w is not programmed into the MAPS\_84000 board, go to section Application SW
4. Install FreeMASTER Application
5. Start FM\_MC56F84000\_PWM\_ADC\_3trigger\_single\_channel.pmp (FreeMASTER Application must be installed before)
6. If the FreeMASTER is not connected (variables values are: ?), check:
  - a. Click at the STOP switch



- b. If an error message is generated after STOP switch click, go to Project/Options Com slider and set the Direct RS232 Port and Speed




7. And the application is running with FreeMASTER.

## FreeMASTER Control

### ADC trigger signals

You can see and check the ADC triggers and PWM Reload signal (one time per period) in the FreeMASTER recorder, represent as GPIOB\_DR\_D3, GPIOB\_DR\_D8 respectively.



These signals can also be seen on the pins:

1. GPIOB3– pin42
2. GPIOB8– pin38

## result signals

In ADC scope, w16Adc\_result0\_1 , w16Adc\_result0\_2 and w16Adc\_result0\_3 value will reflect the status of ANA0 sampled in different times respectively.

1. ANA0 – pin22

The PWM outputs are available on the pins

PWMs with center aligned PWM signals

1. PWMA\_0B – pin68
2. PWMA\_0A – pin69