

# Demo Set-up

---

The SW MC56F84000\_PWM\_ADC demonstrates ADC and ePWM functionality. The PWMA\_SMO module is in Push-pull configuration and triggers an ADC channel of both the ADC modules. FreeMASTER communicate with a PC Computer using OSBDM via SCI1. It is targeted at MC56F84789 and its derivatives.

## H/W Setup

The h/w consists of:

1. MAPS-MC56F84000 populated with MC56F84789 device
2. USB cable connected to MAPS OSBDM connector
3. 5V Power supply

Before the demo starts, the HW with OSBDM link needs to be set-up.

## Application SW

The demo s/w is located in a folder MC56F84000\_PWM\_ADC. The s/w was designed using CodeWarrior CW10.x.

## Development Tools

In order to compile run, load and flash the demo the following steps are necessary:

1. Install CodeWarrior\_CW\_MCU\_v10.x and Run the CodeWarrior
2. Drag and drop < MC56F84000\_PWM\_ADC\project into the opened CodeWarrior CW10.x
3. Clean(if the project is the first time run in your workspace) and Build the application code target MC56F84789\_Internal\_PFlash\_SDM
4. Connect a USB cable between the PC host and the mbed USB port (CN7 on the MAPS-MC56F84000 board)
5. Running/debugging loading the code:
  - a. Run As -> Debug Configuration
  - b. Set the configuration for debug as download for SDM module.

6. Click Debug
7. Start


## Running the demo

Demo is to be controlled using a FreeMASTER communication tool. In order to control the application, the following SW is necessary:


1. FreeMASTER Application Installation  
[http://www.freescale.com/webapp/sps/site/prod\\_summary.jsp?code=FREEMASTER&parentCode=null](http://www.freescale.com/webapp/sps/site/prod_summary.jsp?code=FREEMASTER&parentCode=null)
2. CodeWarrior Connection Server  
this is a part of Freescale CodeWarrior installation, located usually at  
C:\Freescale\CW MCU v10.6\MCU\ccs\bin  
but the ccs\_bld000\_win.zip can also be obtained without the CodeWarrior installation

The following steps are necessary (if continuing from debug mode, goto step 4 and when freemaster is in run state, terminate the code from CodeWarrior using terminate button):

1. Connect Power Supply
2. Connect OSBDM for FreeMASTER control
3. If the application s/w is not programmed into the MAPS\_84000 board, go to section Application SW
4. Install FreeMASTER Application
5. Start FM\_84000\_PWM\_ADC.pmp (FreeMASTER Application must be installed before)
6. If the FreeMASTER is not connected (variables values are: ?), check:
  - a. Click at the STOP switch



- b. If an error message is generate after STOP switch click, go to to Project/Options Com slider and set the Direct RS232 Port and Speed




7. Application runs with FreeMASTER.

## FreeMASTER Control

### Modulated PWM signals

You can see and check the duty cycle and PWM value registers variables which are modulated with linear modulation in the FreeMASTER scope:



The PWMs modulation can be switched off with bEnable\_Modulation – disable. Then the PWM values are constant.

Other possibility is to set all the PWM value registers manually. At that case, disable bEnable\_Calculation – disable and all the PWM dutycycles are updated manually.

The PWM outputs are available on the pins

PWMA\_SMO with Push-pull configuration center aligned PWM signals

1. PWMA\_0B – pin68
2. PWMA\_0A – pin69

### ADC result signals

In ADC scope, ADC\_result0 and ADC\_result8 value will reflect the status of ANA0 and ANB0 respectively.

1. ANA0 – pin22
2. ANB0 – pin33