

	PP0/KWP0/ETRIG0/API_EXTCLK/PWM0	17
	PP1/KWP1/ETRIG1/ECLKX2/PWM1	18
	PP2/KWP2/ETRIG2/PWM2	19
52	PS0/RXD0	20
53	PS1/TXD0	21
54	PS2/RXD1	22
55	PS3/TXD1	23
56	PS4/MISO0	24
57	PS5/MOSI0	
58	PS6/SCK0	32
59	PS7/API_EXTCLK/ECLK/SS0	31
	PT0/IOC0/XIRQ	30
	PT1/IOC1/IRQ	29
	PT2/IOC2	28
12	PJ0/KWJ0/MISO1	27
13	PJ1/KWJ1/MOSI1	26
14	PJ2/KWJ2/SCK1	25
15	PJ3/KWJ3/SS1	
3	PJ4/KWJ4	33
2	PJ5/KWJ5	35
1	PJ6/KWJ6	37
64	PJ7/KWJ7	39
	PAD0/KWAD0/AN0	41
	PAD1/KWAD1/AN1	43
	PAD2/KWAD2/AN2	45
	PAD3/KWAD3/AN3	47
	PAD4/KWAD4/AN4	34
60	PM0/RXCAN	36
61	PM1/TXCAN	38
62	PM2	40
63	PM3	42
	PAD9/KWAD9/AN9/ACMPO	44
	PAD10/KWAD10/AN10/ACMPP	46
	PAD11/KWAD11/AN11/ACMPM	48
11	TEST	
	PAD12/KWAD12	
	PAD13/KWAD13	
	PAD14/KWAD14	
	PAD15/KWAD15	
6	VDDR	
5	VDDX	
7	VSSX	
	PE0/EXTAL	8
50	VDDA	
51	VSSA	10
	PE1/XTAL	
49	VRH	16
9	VSS	
	BKGD/MODC	
	RESET	4

<Value>