

KITMMA9550LEVM Quick Start Guide

1 Unpack the Kit

- Unpack the board. Verify package contents according to the kit website: freescale.com/sensortoolbox.
- Assemble the hardware by connecting the development board to the USB interface board. Both of these board types have a small arrow to indicate where to connect. See the image below. More information can be found at freescale.com/sensingplatform or freescale.com/sensortoolbox.





2 Download Latest Software

- At freescale.com/sensortoolbox download the latest software version.
- This kit uses the Sensor Toolbox software. Follow the on-screen instructions to install the communication driver for the tool. Check back occasionally for software updates.


3 Turn It On

- Plug in the USB and turn the board on using the power switch.
- Run the Sensor Toolbox link on your desktop.
- Explore other sensor kits at freescale.com/sensortoolbox.





KITMMA9550LEVM
Motion-Sensing Platform
Interface Board



MMA9550L
Evaluation Module

Learn More at freescale.com/sensingplatform

Freescale and the Freescale logo are trademarks of Freescale Semiconductor, Inc., Reg. U.S. Pat. & Tm. Off. Xtrinsic is a trademark of Freescale Semiconductor, Inc. All other product or service names are the property of their respective owners.
© 2011 Freescale Semiconductor, Inc.

Doc Number: MMA9550LQSG / REV 0
Agile Number: 926-78477 / REV A